

Quick Installation Guide


Wireless N Broadband Router

Suitable for: N150RT, N300RT, N151RT, N301RT,
N150RH, N300RH, N302R Plus

V3.1507

Copyrights © 2015 by TOTOLINK All rights reserved. Website: <http://www.totolink.net>
Information in this document is subject to change without prior notice.

1 Hardware Installation



LED Indicators

POWER	Light on when router is power on.
CPU	Light is on when systems is working.
WiFi	The indicator light is on when Wi-Fi is enabled.
WAN	Light on when WAN port connected successfully. Light blinking while transmitting or receiving data.
1/2/3/4LAN	Light on when the LAN port successful connected. Light blinking while transmitting or receiving data.

Ports Description


DC IN	Used for connecting the power adapter.
ON/OFF	Used for power on or off the router.
1/2/3/4LAN	Used for connecting the router to local PC.
WAN	Used for connecting the router to the Internet.
Reset/WPS	Reset: Press the button for more than 5 seconds, the router will restore factory settings. WPS: Press the button less than 5 seconds, enable the router WPS function.

NOTE:


1. Please disconnect the power adapter and all cables during thunderstorm weather.
2. Keep away from heat source and keep well ventilated.
3. Please pay attention to the waterproofing and moisture-proof when storing, transporting and running.
4. The power supply must reach the rated current and power.
5. Put the router in flat places.

2 Set Up PC

Windows Vista/7 For Windows Vista or Windows 7 Operating System, please comply with following steps to set up.









Windows 8 For Windows 8 Operating System, please comply with following steps to set up.



3 Set Up Router

Please set up the router following below steps.



Router Quick Setup by Wi-Fi Devices

